

Qwik Freezer Kits WOC	Qwik-Freezer Pipe Freeze Kit Contents By Model
<p>QF 1500WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 3/8" to 1-1/2" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 101 Jacket (3/8" to 3/4" pipe) • 1 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 1 – QF 800 10' High Pressure Hose • 1 – QF 801 Cylinder Valve Adapter • 1 – QF 807 Pair Insulated Safety Gloves • 1 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 808 Small Carrying Case • 1 – QF 818 Timing Pad
<p>QF 1700WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Double Pipe Freezing Kit for 3/8" to 1-1/2" I.D.</p> <ul style="list-style-type: none"> • 2 – QF 101 Jacket (3/8" to 3/4" pipe) • 2 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 2 – QF 800 10' High Pressure Hose • 2 – QF 801 Cylinder Valve Adapter • 1 – QF 807 Pair Insulated Safety Gloves • 1 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 808 Small Carrying Case • 1 – QF 818 Timing Pad
<p>QF 2000WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 3/4" to 1-1/2" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 1 – QF 800 10' High Pressure Hose • 1 – QF 801 Cylinder Valve Adapter • 1 – QF 807 Pair Insulated Safety Gloves • 1 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 808 Small Carrying Case • 1 – QF 818 Timing Pad
<p>QF 2200WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Double Pipe Freezing Kit for 3/4" to 1-1/2" I.D.</p> <ul style="list-style-type: none"> • 2 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 2 – QF 800 10' High Pressure Hose • 2 – QF 801 Cylinder Valve Adapter • 1 – QF 807 Pair Insulated Safety Gloves • 1 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 808 Small Carrying Case • 1 – QF 818 Timing Pad

<p>QF 3000WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 3/8" to 3" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 101 Jacket (3/8" to 3/4" pipe) • 1 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 1 – QF 103 Jacket (1-1/2" to 3" pipe) • 2 – QF 800 10' High Pressure Hose • 2 – QF 801 Cylinder Valve Adapter • 1 – QF 807 Pair Insulated Safety Gloves • 1 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 808 Small Carrying Case • 1 – QF 818 Timing Pad
<p>QF 3200WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Double Pipe Freezing Kit for 3/8" to 3" I.D.</p> <ul style="list-style-type: none"> • 2 – QF 101 Jacket (3/8" to 3/4" pipe) • 2 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 2 – QF 103 Jacket (1-1/2" to 3" pipe) • 4 – QF 800 10' High Pressure Hose • 4 – QF 801 Cylinder Valve Adapter • 1 – QF 807 Pair Insulated Safety Gloves • 1 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 2 – QF 808 Small Carrying Case • 1 – QF 818 Timing Pad
<p>QF 4000WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 3/8" to 4" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 101 Jacket (3/8" to 3/4" pipe) • 1 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 1 – QF 103 Jacket (1-1/2" to 3" pipe) • 1 – QF 104 Jacket (3" to 4" pipe) • 4 – QF 800 10' High Pressure Hose • 2 – QF 801 Cylinder Valve Adapter • 2 – QF 802 Tee Connector (for use with QF 801) • 1 – QF 807 Pair Insulated Safety Gloves • 1 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 808 Small Carrying Case • 1 – QF 815 Timing Board & Pads
<p>QF 4100WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 3" to 4" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 104 Jacket (3" to 4" pipe) • 4 – QF 800 10' High Pressure Hose • 2 – QF 801 Cylinder Valve Adapter • 2 – QF 802 Tee Connector (for use with QF 801) • 1 – QF 807 Pair Insulated Safety Gloves • 1 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 808 Small Carrying Case • 1 – QF 815 Timing Board & Pads

<p>QF 4200WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Double Pipe Freezing Kit for 3/8" to 4" I.D.</p> <ul style="list-style-type: none"> • 2 – QF 101 Jacket (3/8" to 3/4" pipe) • 2 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 2 – QF 103 Jacket (1-1/2" to 3" pipe) • 2 – QF 104 Jacket (3" to 4" pipe) • 8 – QF 800 10' High Pressure Hose • 4 – QF 801 Cylinder Valve Adapter • 4 – QF 802 Tee Connector (for use with QF 801) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 2 – QF 804 Rubber Mallet • 2 – QF 808 Small Carrying Case • 1 – QF 815 Timing Board & Pads
<p>QF 4250WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Double Pipe Freezing Kit for 3" to 4" I.D.</p> <ul style="list-style-type: none"> • 2 – QF 104 Jacket (3" to 4" pipe) • 8 – QF 800 10' High Pressure Hose • 4 – QF 801 Cylinder Valve Adapter • 4 – QF 802 Tee Connector (for use with QF 801) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 2 – QF 804 Rubber Mallet • 2 – QF 808 Small Carrying Case • 1 – QF 815 Timing Board & Pads
<p>QF 6000WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 3/8" to 6" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 101 Jacket (3/8" to 3/4" pipe) • 1 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 1 – QF 103 Jacket (1-1/2" to 3" pipe) • 1 – QF 104 Jacket (3" to 4" pipe) • 1 – QF 106 Jacket (5" to 6" pipe) • 4 – QF 800B 16' High Pressure Hose • 3 – QF 801 Cylinder Valve Adapter • 3 – QF 814 Hose Assembly (for use with QF 106) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 813 Large Carrying Case • 1 – QF 815 Timing Board & Pads
<p>QF 6100WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 5" to 6" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 106 Jacket (5" to 6" pipe) • 3 – QF 800B 16' High Pressure Hose • 3 – QF 801 Cylinder Valve Adapter • 3 – QF 814 Hose Assembly (for use with QF 106) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 1 – QF 813 Large Carrying Case • 1 – QF 815 Timing Board & Pads

<p>QF 6200WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Double Pipe Freezing Kit for 3/8" to 6" I.D.</p> <ul style="list-style-type: none"> • 2 – QF 101 Jacket (3/8" to 3/4" pipe) • 2 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 2 – QF 103 Jacket (1-1/2" to 3" pipe) • 2 – QF 104 Jacket (3" to 4" pipe) • 2 – QF 106 Jacket (5" to 6" pipe) • 8 – QF 800B 16' High Pressure Hose • 6 – QF 801 Cylinder Valve Adapter • 6 – QF 814 Hose Assembly (for use with QF 106) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 2 – QF 804 Rubber Mallet • 2 – QF 813 Large Carrying Case • 1 – QF 815 Timing Board & Pads
<p>QF 6250WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Double Pipe Freezing Kit for 5" to 6" I.D.</p> <ul style="list-style-type: none"> • 2 – QF 106 Jacket (5" to 6" pipe) • 6 – QF 800B 16' High Pressure Hose • 6 – QF 801 Cylinder Valve Adapter • 6 – QF 814 Hose Assembly (for use with QF 106) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 2 – QF 804 Rubber Mallet • 2 – QF 813 Large Carrying Case • 1 – QF 815 Timing Board & Pads
<p>QF 8000WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 3/8" to 8" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 101 Jacket (3/8" to 3/4" pipe) • 1 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 1 – QF 103 Jacket (1-1/2" to 3" pipe) • 1 – QF 104 Jacket (3" to 4" pipe) • 1 – QF 106 Jacket (5" to 6" pipe) • 1 – QF 108 Jacket (7" to 8" pipe) • 4 – QF 800B 16' High Pressure Hose • 4 – QF 801 Cylinder Valve Adapter • 4 – QF 814 Hose Assembly (for use with QF 106) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 2 – QF 813 Large Carrying Case • 1 – QF 815 Timing Board & Pads
<p>QF 8100WOC Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Single Pipe Freezing Kit for 7" to 8" I.D.</p> <ul style="list-style-type: none"> • 1 – QF 108 Jacket (7" to 8" pipe) • 4 – QF 800B 16' High Pressure Hose • 4 – QF 801 Cylinder Valve Adapter • 4 – QF 814 Hose Assembly (for use with QF 106) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 1 – QF 804 Rubber Mallet • 2 – QF 813 Large Carrying Case • 1 – QF 815 Timing Board & Pads

<p>QF 8200 Pipe Freeze Kit Without CO2 Cylinder(s)</p>	<p>Double Pipe Freezing Kit for 3/8" to 8" I.D.</p> <ul style="list-style-type: none"> • 2 – QF 101 Jacket (3/8" to 3/4" pipe) • 2 – QF 102 Jacket (3/4" to 1-1/2" pipe) • 2 – QF 103 Jacket (1-1/2" to 3" pipe) • 2 – QF 104 Jacket (3" to 4" pipe) • 2 – QF 106 Jacket (5" to 6" pipe) • 2 – QF 108 Jacket (7" to 8" pipe) • 8 – QF 800B 16' High Pressure Hose • 8 – QF 801 Cylinder Valve Adapter • 8 – QF 814 Hose Assembly (for use with QF 106) • 2 – QF 807 Pair Insulated Safety Gloves • 2 – QF 817 Pair Safety Glasses • 2 – QF 804 Rubber Mallet • 2 – QF 813 Large Carrying Case • 2 – QF 815 Timing Board & Pads
<p>QFAL 20</p>	<ul style="list-style-type: none"> • 20lb. Aluminum CO2 Cylinder • With Dip Tube and Carry Handle
<p>QFAL 50</p>	<ul style="list-style-type: none"> • 50lb. Aluminum CO2 Cylinder • With Dip Tube and Steel Cap